





HEXPACT

360°- Hinge Shield


Built for Daily Classroom Drops. Designed for Better Hinge Protection.



5-Layer Protection
Designed for stronger 360° protection




Front Secure Lock
Helps prevent screen damage inside bags



Dual Corner Airbag
Absorbs corner impact from drops



Hinge Shield
Reinforced hinge protection



Max Ventilation
Keeps devices cool during use



Barcode Friendly
No need to remove case for scanning



Military Drop Protection
(4 ft tested)



Eco Guard
(CA65 Compliant)



Custom Colors Available



Contact our sales team today
917-209-0841 | info@ibenzer.com

IBENZER
Live Smart, Protect Smarter

www.ibenzer.com



HEXPACT



360 - Hinge Shield

COMPATIBLE MODELS - ALL PART NUMBERS

Brand	Model	Size	Part Number
HP	ProBook Fortis G10 / G11	14"	LC-HPE3-HP14PB-G10-BK
Acer	Chromebook 511 C736	11"	LC-HPE3-AC11C736-BK
Lenovo	Chromebook 100e/w Gen 4	11"	LC-HPE3-LNV100E4-BK

Compatible with the most commonly used Chromebook models in K12 environments

Easy open design — no force needed for daily use
Helps reduce hinge damage from improper handling






HEXPACT


360 - Hinge Shield

Quick installation — no tools required


Installation




- 1 Slide the top cover down and align the panel under the upper side clips until the panel reaches the top edge of the top cover.




- 2 Gradually press the sides of the panel starting from the top, pushing the panel into the cover until reaching the bottom of the panel.




- 3 Snap the top cover onto the panel by pressing the clips on each side, ensuring the top cover is securely in place.



- 4 Close the laptop, insert the leaf portion of the top cover into the slot on the bottom cover.




- 5 Open the laptop and insert the bottom edge of the laptop into the bottom cover until the bottom edge touches the edge of the case. Tuck in the clips on both sides to securely fasten the bottom cover to the bottom panel.




- 6 Snap the bottom cover onto the panel by pressing the rear corner clips, ensuring the bottom cover is securely in place.

Quick removal — no tools required


Removal




- 1 Detach the rear corner clips.




- 2 Detach the clips on each side of the bottom cover by moving outward.




- 3 Close the laptop, remove leaf portion of the top cover from the slot on the bottom cover.



- 4 Lift the rear corner clips outward.



- 5 Detach the clips on each side of the top cover by lifting both sides from the bottom edge to the top edge.



- 6 Slide out the top cover to remove it.