





# HEXPACT

## 360°- Hinge Shield


**Built for Daily Classroom Drops. Designed for Better Hinge Protection.**




**5-Layer Protection**  
Designed for stronger 360° protection



**Front Secure Lock**  
Helps prevent screen damage inside bags



**Dual Corner Airbag**  
Absorbs corner impact from drops



**Max Ventilation**  
Keeps devices cool during use



**Hinge Shield**  
Reinforced hinge protection



**Barcode Friendly**  
No need to remove case for scanning



**Military Drop Protection**  
(4 ft tested)



**Eco Guard**  
(CA65 Compliant)



**Custom Colors Available**



Contact our sales team today  
917-209-0841 | info@ibenzer.com

**IBENZER**  
Live Smart, Protect Smarter

www.ibenzer.com



# HEXPACT

## 360° - Hinge Shield



### COMPATIBLE MODELS - ALL PART NUMBERS

Brand	Model	Size	Part Number
HP	ProBook Fortis G10 / G11	14"	LC-HPE3-HP14PB-G10-BK
Acer	Chromebook 511 C736	11"	LC-HPE3-AC11C736-BK
Lenovo	Chromebook 100e Gen 4	11"	LC-HPE3-LNV100E4-BK

Compatible with the most commonly used Chromebook models in K12 environments

## Easy open design — no force needed for daily use

Helps reduce hinge damage from improper handling



Contact our sales team today  
917-209-0841 | [info@ibenzer.com](mailto:info@ibenzer.com)

**IBENZER**  
Live Smart, Protect Smarter

[www.ibenzer.com](http://www.ibenzer.com)




# HEXPACT


## 360° Hinge Shield

### Quick installation — no tools required

#### Installation




- 1 Slide the top cover down and align the panel under the upper side clips until the panel reaches the top edge of the top cover.




- 2 Gradually press the sides of the panel starting from the top, pushing the panel into the cover until reaching the bottom of the panel.




- 3 Snap the top cover onto the panel by pressing the clips on each side, ensuring the top cover is securely in place.



- 4 Close the laptop, insert the leaf portion of the top cover into the slot on the bottom cover.




- 5 Open the laptop and insert the bottom edge of the laptop into the bottom cover until the bottom edge touches the edge of the case. Tuck in the clips on both sides to securely fasten the bottom cover to the bottom panel.




- 6 Snap the bottom cover onto the panel by pressing the rear corner clips, ensuring the bottom cover is securely in place.

### Quick removal — no tools required


#### Removal




- 1 Detach the rear corner clips.




- 2 Detach the clips on each side of the bottom cover by moving outward.




- 3 Close the laptop, remove leaf portion of the top cover from the slot on the bottom cover.



- 4 Lift the rear corner clips outward.



- 5 Detach the clips on each side of the top cover by lifting both sides from the bottom edge to the top edge.



- 6 Slide out the top cover to remove it.